

Taking Care of Your UltraLux Clean

Cleaning Your UltraLux Clean

- Sometimes you may need to clean your UltraLux Clean. For best results, we recommend rinsing out the UltraLux Clean after creating and using hypochlorous acid or in between uses.
 - To clean the bottle, rinse out the bottle a few times with clean water.
 - To clean the nozzle, fill the bottle with clean water and do a continuous spray for approximately 30 seconds to rinse out the internal components
 - You can wipe the Clean with a damp cloth as needed.
 - Do not use soap or other cleaning products on the bottle or nozzle as that can damage the product.
 - Do not immerse the nozzle in water.

Maintenance

For best results, store the UltraLux Clean in a dry, cool, well-ventilated place, keeping the device out of direct sunlight, extreme heat, and cold.

Do not adjust or tamper with the battery. Using metallic tools to tamper with the battery may cause the battery and/or product to short circuit leading to product failure, burnout, and possible explosion.

To extend battery life it's recommended to store the UltraLux Clean at a partially charged level (between 40-60% or 2 LED lights). If not in regular use, it's recommended to charge it to a partially charged level every 3 months.

Product Specifications

Product Dimensions	10.75" x 4.5" x 3.85"
Product Weight	1.07 lbs
Voltage	DC 3.7 Volt
Power	3.7 Watts
Bottle Capacity	500 ML
Battery	2200 mAh
Battery Life Per Charge	3-4 hours
Battery Recharge Time	3-4 hours
Product Materials	Silicon, Plastic, Metal

Cleaning Specifications

These are the results when the UltraLux Clean was tested by a non-biased third party. Individual results may vary.

Amount of Water	PPM of Hypochlorous Acid	pH level
500 mL with Cleaning Powder	Up to 600 PPM	Between 3-6 pH
250 mL with Cleaning Powder	Up to 750 PPM	Between 3-6 pH
100 mL with Cleaning Powder	Up to 3000 PPM of HOC	Between 3-6 pH

Warnings — Read Before First Use

1. **Do not** repeatedly run the electrolysis cycle. Excessive running of the electrolysis cycle can lead to pressurized build up causing the product to leak and/or explode.

Warnings — Read Before First Use

2. **Use only** the manufacturer's recommended accessories and replacement parts.
3. **This is not a toy.** Do not allow children to play with or use the device without adult supervision.
4. **Do not** use a damaged cord or plug. Do not use the UltraLux Clean if it is damaged or it is not working as described.
5. **Do not** use the device when the nozzle is clogged. Keep the nozzle free of dirt, debris, or anything that may reduce flow or cause clogging.
6. **Always** use proper voltage. Using improper voltage may result in damage to the device, spray motor, and possibly injury.
7. **The UltraLux Clean base is not waterproof.** Do not submerge or get excessive water in the base.
8. **Do not** use corrosive liquid or ethyl alcohol-type disinfectant inside or outside of the device.
9. **Do not** allow the device to freeze. Always store indoors. Freezing will damage the spray motor.
10. **Do not** attempt to disassemble the device.
11. **Do not** charge the battery overnight or overcharge it.
12. **Keep the device away** from extreme heat or fire.
13. **Only** charge the UltraLux Clean with the included charger, both the battery and the base. Using a different charger may lead to product and/or battery failure, burnout, and may cause serious injury.

Warranty

The UltraLux Clean has a 1-year manufacturer defect warranty. To see the entire product warranty, visit <https://ultraluxhealth.com/warranty/>.

ULTRALUX CLEAN



USER MANUAL

Meet The Simpler Way to Clean — the UltraLux Clean

Congratulations on choosing to live healthier — and cleaner — by purchasing the UltraLux Clean. The UltraLux Clean is sure to simplify and enhance any cleaning routine.


Before the UltraLux Clean, it used to require nearly a dozen different cleaning solutions and chemically-saturated surfaces to get your home reasonably clean. But with every spray, wipe, or scrub, you were spreading another near-infinite layer of chemicals over your home.

The UltraLux Clean puts an end to over-stuffed cleaning cabinets and the unseen chemical invasion on your home.

What's the UltraLux Clean's Secret?

- **A Medical Grade Sanitizer In Your Home.** With the UltraLux Clean you can create a medical-grade cleaning and sanitizing solution that's 80 times stronger than bleach in less than 5 minutes.
- **The perfect balance of effective and family-friendly.** The UltraLux Clean combines the effectiveness of chemical cleaners with the safety of organic, all-natural cleaners.
- **Refillable and Rechargeable.** It costs approximately \$0.000015 to refill and recharge your UltraLux Clean, making it significantly cheaper than store-bought cleaners. And with every refill that's one less single-use plastic being thrown away. A cost-effective, powerful, all-natural cleaner that's environmentally friendly — that's what we call a win, win, win.


Parts Overview




Using the UltraLux Clean

How to Make Hypochlorous Acid

1. Unscrew and remove the nozzle from the bottle.
2. Remove the scoop spoon from the bottom of the base.




3. Fill the bottle with lukewarm water and add 1 scoop of the included Cleaning Powder.



Using the UltraLux Clean

4. Tighten the nozzle and gently shake for 15-30 seconds to dissolve the Cleaning Powder.
5. Place on the base and run the electrolysis cycle for 5 minutes.
 - A. When electrolysis is creating hypochlorous acid, the bottle will display a white light. The light will turn off when the electrolysis cycle has been completed.




6. Let the cleaning begin!

How to Use the UltraLux Clean

Once the solution has been created, the UltraLux Clean is ready to tackle the hardest cleaning and sanitizing spots.

1. **Press and hold the power button** on the back of the sprayer for 3 to 5 seconds to turn on the UltraLux Clean.
 - A. The sprayer battery life is indicated by the yellow lights on the side of the sprayer. You may need to charge the sprayer before your first use.
2. **Adjust the control nozzle.** The UltraLux Clean can spray both a fine mist and a direct stream. These types of sprays can be controlled by tightening or loosening the control nozzle.
3. **Quick Spray:** Tap and hold the spray trigger for a quick spray.



4. **Continuous Spray:** Quickly double-tap the spray trigger for a long, continuous spray. Click the trigger again to end the continuous spray.